

WARNING

- Electrical wiring should be done by a qualified person(s) in accordance with all applicable codes and standards, including fire-rated construction. An unqualified person doing the work could result in fire, electric shock or injury.
- This switch uses 120 V AC, Max 16 Amp. Do not connect to other voltage or over current rate since fire, electric shock or damage could result.
- Be sure to switch power OFF at service panel before wiring.

< CONNECTING POWER SUPPLY WIRES >

1. A 2-1/2" deep Wall Box must be used to allow space for wire connections between switch and 120 volt Power Input Leads.
2. Connect the electrical wires to the way in a right diagram. Connect wires tightly and securely using wire connectors (not supplied).
3. Attach the wall plate, and secure it with 2 screws.
4. Turn on the electrical circuit to the power unit. Check the ventilating functions at each speed control positions. Make sure that the range hood has no abnormal noises and/or vibration.

Your installation is now complete.
If you should require service or replacement parts on your ventilation system, contact:

Fuji Industrial USA, Inc.
16300 Christensen Rd, #212 Seattle, WA 98188
1-888-547-9880




FIG 1 < Connection Diagram >




FIG 2

READ AND SAVE THESE INSTRUCTIONS.
Keep this manual in a convenient place for future reference.
FUJI INDUSTRIAL CO.,LTD .